



ON TIME WILDLIFE FEEDERS IS NOT RESPONSIBLE FOR VARMINT DAMAGE TO YOUR FEEDER UNIT. HEAVY SCREEN WIRE IS RECOMMENDED TO SHIELD YOUR UNIT FROM VARMINTS.


RICE BRAN FEEDER INSTRUCTIONS ITEM# 73000

STEP 4: Setting the digital timer.


STEP 1: If the battery or batteries are already connected, unplug the battery pack for 15 seconds—then plug the battery pack back in. This clears out all of the memory in the unit.




STEP 2: Use the up or down arrow keys to change the 12:00pm setting to the correct time of day. (Also make sure you are on the correct AM or PM.) There are no buttons to move the AM or PM. You will have to fully cycle the clock to get to the correct time setting. You can pulse the keys, or to rapidly advance the movement of the time, you can hold the key down and after a moment, the time will begin its rapid advancement. After the correct time of day is on the display, press the SELECT/ENTER button one time. The display should show FIGURE 2. Now proceed to STEP 3.




STEP 3: The 7:00am setting that now appears on the display has been factory installed. This is a very common time that is used often, but if the 7:00am setting is not desired, you can pulse or hold the up or down arrow buttons until the desired time is displayed. (Please note the small number 1 in the lower left hand side of the display. – This is the first feed time for the unit. A total of 6 are possible. – We will refer to this number as we move to the following steps.) After the desired feed time is displayed, press the SELECT/ENTER button one time. The display will show FIGURE 3.



STEP 4: The display should now show FIGURE 3. Note the number 1 in the lower left side of the display (It shows this is still concerning your number 1 feeding). The 08 setting is factory installed and is a very common setting. If this setting is not what you desire, press the up or down arrow key until the number of seconds of run time you want are correct. A possible of 1 to 30 seconds can be set. After the correct number of seconds are on the display, press the SELECT/ENTER button one time. The display should now show FIGURE 4.



STEP 5: Note the number 1 in the lower left side of the display. This is still concerning your number 1 feeding. Speed – refers to the speed of the motor. There are 3 possible speeds of the motor: 50%, 75%, and 100%. The 100% is used most often in the field and is therefore factory set to automatically show on the screen. If this speed is not desired simply use the up or down arrow buttons to set the speed you would like to use. After the correct speed is displayed, press the SELECT/ENTER button one time. The display should now show FIGURE 5.



STEP 6: At this point, your display should appear similar to FIGURE 5. The number 2 in the lower left hand bottom of the display indicates the second feed time. The 4:00pm is factory preset, and is another very common time to feed. If this is not the time you would like, press the up or down key to set the desired time for the second feeding. Once set press the SELECT/ENTER button one time.

