

INSTRUCTIONS FOR THE ELITE MODEL #11113

SAFETY GLASSES MUST BE USED AT ALL TIMES WHILE WORKING WITH THIS EQUIPMENT

- I. BACK OUT THE BOTTOM SET SCREW UNDER THE FRONT LABEL OF THE FEEDER HOUSING.
- II. BATTERY INSTALLATION:
INSTALL AA (ALKALINE ONLY) BATTERIES INTO THE BATTERY HOLDER. USE CARE TO MATCH + AND – SIGNS MARKED INSIDE THE BATTERY HOLDER. (DURACELL AND EVEREADY BRANDS WERE USED IN OUR STANDARD TESTING.) SNAP BATTERY PACK TO UNIT'S RED AND BLACK BATTERY WIRES. NOTE: UNIT DOES NOT REQUIRE A BATTERY FOR CLOCK.

BATTERY LIFE:

1. BATTERY LIFE WILL BE DETERMINED BY THE JOB YOU WANT YOUR ELITE TO PERFORM. THE STANDARD FEED TIME IS 8 SECONDS OF MOTOR RUN TIME TWICE A DAY. THIS WILL GIVE 6 MONTHS OF GOOD BATTERY PERFORMANCE. HOWEVER, IF YOU CHOOSE TO FEED LONGER RUN TIMES OR MORE TIMES A DAY THEN BATTERY LIFE IS DECREASED IN DIRECT PROPORTION.
2. BATTERY LIFE IS ALSO AFFECTED BY THE GAP BETWEEN THE SPINPLATE AND MOUTH OF THE FUNNEL. FOR STANDARD FEEDINGS, WE RECOMMEND A 3/8" GAP BETWEEN THE SPINPLATE AND THE BOTTOM OF THE FUNNEL FOR CORN AND MOST OTHER FEEDS.
 - a. EXAMPLE: IF YOU RAISE THE GAP TO 1/2", THE UNIT WILL THROW 50% MORE FEED THAN THE 3/8" SETTING AND THEREFORE OVERLOADS THE MOTOR AND DECREASES BATTERY LIFE.
3. THE 3 MOTOR SPEEDS WILL ALSO AFFECT BATTERY LIFE: 100% SPEED: STANDARD 4 MONTH'S BATTERY LIFE. 50% SPEED: LENGTHENS BATTERY LIFE.

OPTIONAL ACCESSORY: C-CELL BATTERY PACKS CAN BE PURCHASED THROUGH YOUR LOCAL DEALER OR THE ON TIME FACTORY. THIS REQUIRES 8 C-CELL BATTERIES (ALKALINE ONLY) WHICH WILL YIELD 3 TIMES THE LONGEVITY OF THE AA BATTERY PACK.

- III. PROGRAMMING YOUR ELITE: PLEASE SEE SECOND PAGE OF INSTRUCTIONS FOR DETAILS ON PROGRAMMING THE ELITE MODULE.
 - a. PLEASE NOTE: THE SCREEN WILL INDICATE ALL CHARACTERS FOR 1 SECOND ONCE BATTERIES ARE PLUGGED INTO MODULE. THEN THE SCREEN WILL SHOW 12:00PM. IF NO PROGRAMMING ACTIVITY IS INITIATED, THE UNIT WILL AUTOMATICALLY SET ITSELF AT 12:00PM NOON FOR A 5 SECOND RUN TIME.
- IV. TO TEST YOUR ELITE:
THE TEST BUTTON CAN ONLY BE USED WHILE ON THE "ARMED" SCREEN. PRESSING THE TEST BUTTON WILL SEQUENCE THE SCREEN TO A COUNTDOWN FROM 10 TO 0. IT WILL THROW WHEN IT REACHES 0. THE SCREEN WILL RETURN TO "ARMED" AUTOMATICALLY WHEN THE TEST IS COMPLETE.

NOTE: FOR BATTERY CONSERVATION, THE SCREEN WILL AUTOMATICALLY GO BLANK AFTER 2 MINUTES OF NO KEY ACTIVITY. TO REVIVE THE SCREEN, PRESS ANY KEY. THIS WILL NOT INTERFERE WITH PREVIOUS PROGRAMMING.

TO CLEAR ALL PROGRAMMING, DISCONNECT BATTERY AND RECONNECT.

TO MODIFY A SETTING: PRESS ENTER KEY REPEATEDLY UNTIL THE SETTING APPEARS THAT YOU WANT TO ADJUST.

FOR TECHNICAL ASSISTANCE, PLEASE CALL CUSTOMER SERVICE @ 1-800-488-3006.